


AMERICAN SERIES STRATOCASTER HH 0117100

MODEL	MODEL NO.
AM SERIES STRAT HH	0117100
AM SER STRAT HH-HT	0117130



SWITCH VOLUME
POT (UP & DOWN)

- MV = MASTER VOLUME
- NT = NECK TONE
- BT = BRIDGE TONE
- SER = COIL PAIR IN SERIES
- PAR = COIL PAIR IN PARALLEL
- INS = INSIDE COILS IN PARALLEL,
SERIES WITH OUTSIDE COIL

5 WAY SWITCH POSITION,					SWITCH UP
					← 5 WAY SWITCH POSITION
MV NT	MV NT	MV NT+BT	MV BT	MV BT	← CONTROL
					← NECK PICKUP (A)
					← BRIDGE PICKUP (B)

5 WAY SWITCH POSITIONS,					SWITCH DOWN
					← 5 WAY SWITCH POSITION
MV NT	MV NT	MV NT+BT	MV BT	MV BT	← CONTROL
					← NECK PICKUP (A)
					← BRIDGE PICKUP (B)

	PICKUP IS ON	<i>A</i> PICKUP (NECK)
	PICKUP IS ON	<i>B</i> PICKUP (BRIDGE)
	PICKUP IS OFF	