


AMERICAN SERIES TELECASTER HS W/O PICKGUARD 0118660



| 3WAY SWITCH POSITION, | | | SWITCH UP |
|-----------------------|----------------|------------|----------------------------------|
| | | | ← 3 WAY SWITCH POSITION |
| MV+MT 1+2 | MV+MT 1+2+3 | MV+MT 3 | ← CONTROL |
| | | | ← NECK PICKUP (A) COILS 1 & 2 |
| | | | ← BRIDGE PICKUP (B) COIL 3 |

| 3 WAY SWITCH POSITIONS. | | | SWITCH DOWN |
|-------------------------|----------------|--------------|----------------------------------|
| | | | ← 3 WAY SWITCH POSITION |
| MV+MT 1x2 | MV+MT 1x2x3 | MV+MT 2X3 | ← CONTROL |
| | | | ← NECK PICKUP (A) COILS 1 & 2 |
| | | | ← BRIDGE PICKUP (B) COIL 3 |

| | | |
|--|---------------|-------------------|
| | PICKUP IS ON | A PICKUP (NECK) |
| | PICKUP IS OFF | B PICKUP (BRIDGE) |

- MV = MASTER VOLUME
- MT = MASTER TONE
- "x" = SERIES CONNECTION
- "+" = PARALLEL CONNECTION
- "()" = INDICATES PARIED CONNECTION