
















SWITCH & CONTROL FUNCTION

3 WAY SWITCH POSITION			
			
T1	T2	NT	
			← NECK PICKUP (A)
			← MIDDLE PICKUP (B)
			← BRIDGE PICKUP (C)
	PICKUP IS ON		 INDICATES POSITION OF 3 WAY SWITCH
	PICKUP IS OFF		
A	PICKUP (NECK)		
B	PICKUP (MIDDLE)		
C	PICKUP (BRIDGE)		
NT	NO TONE		

