



60's TELECASTER 0131600
SWITCH & CONTROL FUNCTION



NECK PICKUP

BRIDGE PICKUP



3 WAY SWITCH
(SEE FUNCTION DIAGRAM)

VOLUME CONTROL

TONE CONTROL