


BUDDY GUY POLKA DOT STRATOCASTER® 013-8802

SWITCH & CONTROL FUNCTION



5 WAY SWITCH POSITION					
5	4	3	2	1	
T1	T1&T2	T2	T2	NT	
					← NECK PICKUP (A)
					← MIDDLE PICKUP (B)
					← BRIDGE PICKUP (C)
	PICKUP IS ON				 INDICATES POSITION OF 5 WAY SWITCH
	PICKUP IS OFF				
A	PICKUP (NECK)				
B	PICKUP (MIDDLE)				
C	PICKUP (BRIDGE)				
NT	NO TONE				

